





Shop Fox® Featherboard Model D3096 Instruction Sheet

Congratulations on the purchase of your new Shop Fox® Featherboard! When used properly, this important safety device is designed to keep the stock tight against the fence and to protect the operator against kickback. For safe and effective use, only use this featherboard in a standard $\frac{3}{4}$ " miter gauge slot. For additional safety, use a Shop Fox® push stick when feeding stock into the blade.

To use your Shop Fox® Featherboard:

1. Slide the aluminum locking insert completely in the $\frac{3}{4}$ " table saw miter gauge slot.
2. Place your stock evenly against the fence like you would normally do before cutting. Make sure it is about $\frac{1}{2}$ " behind the blade.
3. Position the fingered edge of the featherboard against the edge of the stock, so that all of the fingers contact the stock. Slide the featherboard and aluminum insert toward the blade until the first finger is nearly even with the end of the stock, which should be $\frac{1}{2}$ " away from the blade.
4. Swivel the aluminum hold-down over the stock, so that it rests on the top of the stock and directly behind the featherboard.
5. Double check the stock and featherboard to ensure they are properly positioned, then tighten the wing nut to secure them in place. Try to move the assembly by hand to make sure it is tight.
6. When the featherboard assembly is secure, start the saw and feed the stock into the blade as normal.



**Shop Fox® is a registered trademark of
Woodstock International, Inc.**

COPYRIGHT © 2002 BY WOODSTOCK INTERNATIONAL, INC.

**WARNING: NO PORTION OF THIS INSTRUCTION SHEET MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT
THE WRITTEN APPROVAL OF WOODSTOCK INTERNATIONAL, INC.**

www.woodstockinternational.com